

## **APPLICATION** INSTRUCTIONS



DryErase



## Muraspec



## **Drying Time**

Day 1 - Paint is dry to touch

Day 7 - Ready to write on and dry wipe

Day 28 - Cleaning products can be used

## APPLICATION INSTRUCTIONS White & Clear Surface Paint

All instructions must be followed carefully

Safety First

Please read the safety data sheet provided. Wear Protective Gloves (supplied) and Safety Glasses (not supplied).

Measure Up

Measure the area accurately and ensure you have enough paint to cover the calculated area. Don't under estimate the coverage - if the paint is applied too sparingly it will not perform.

Prepare

Protect the area around the surface you wish to paint - mask off the edges using masking tape. Check the surface to be painted. Fill any holes or cracks in the surface with a good quality filler according to the manufacturer's instructions. Use the sanding block in your kit to smooth the filled surface. Prime the filled areas.

Prime

Apply at least 2 coats (3 coats for fresh plaster) of white primer to create a solid uniformed base on which to apply your MemErase DryErase paint. Deeper existing colours may require more than 2 coats. Ordinary emulsion/latex paint is not suitable as a primer:

Use Clear primer before applying Clear MemErase DryErase Surface paint when painting:

- · New wood or composite material
- · Porous surfaces such as new plaster or concrete
- Wallpaper

Use a short pile or foam roller to apply the primer (not provided). The roller supplied with your kit is for the once only application of the MemErase DryErase Paint it can't be washed out for use with primer or a second time around. The surface must be clean and dry prior to applying the paint. Stir the primer thoroughly before use. Each coat takes 2-4 hours to dry. Leave 12 hours after the final coat before painting.

Mix and stir

Pour both "Part" 1's into "Part" 2 It is very important the mixture is stirred thoroughly for no less than 5 minutes using the stirring stick supplied with your kit. Apply within one hour of mixing using the foam roller supplied in your kit. Avoid any contact with water or moisture. Ensure all equipment, such as the tray and roller etc. is completely dry.

Apply

Start applying the Memerase Paint by filling in from the masked off edges using a 4 inch wide foam roller. Using the technique below paint the larger areas using the roller supplied with your kit. Start from the top on one side, and paint a section one metre wide by one metre deep, when this is covered move down to the second square metre and paint this, and so on to the third, working metre by metre down to the bottom. After reaching the bottom of the first section pass your roller over the entire painted surface again from top to bottom at least ten times to ensure you have achieved a solid uniformed paint film. Move back up to the top of the wall, and start again on the next metre wide section, working back down metre by metre to the bottom. As before pass your roller top to bottom at least ten times. Continue with this process until the whole area is fully painted. Mark up your ready to use notice for 7 days from the day of application.

Inspect

As you apply the paint to each section, examine the painted surface from several angles to ensure there are no pinholes, missed, or thin areas. If there are go over these while the paint film is still wet. Once you are happy with your paint finish, carefully remove the masking tape within 1 hour of painting.

Time to Dry

1 Day - Touch dry 7 Days - Ready to write on

28 Days - Cleaning products can be used if required

